

Page

Front Wheel Suspension

Technical Data	40 - 01
Tightening torque for front axle	40 - 02
Front axle modifications for 944 turbo special model "S"	40 - 04
Front wheel bearings - adjustment	40 - 1
Checking caps of ball joints on control arms and tie rods	40 - 2
Height - adjustable strut, disassembly and assembly	40 - 3
Tolerance groups of coil spring	40 - 6
Koni vibration damper	40 - 8
Koni vibration shock absorber with outside rebound travel adjustment	40 - 9

Rear Wheel Suspension, Axle Shaft

Technical Data	42 - 01
Tightening torque for rear axle	42 - 02
Koni vibration damper / Koni damper - adjusting	42 - 1

Wheels, Tires, Alignment

Wheels and tires	44 - 01
Sample measuring chart up to end of MY '89	44 - 03
Sample measuring chart as of MY '90	44 - 1
Adjustment values for wheel alignment	44 - 2
Vehicle measurement	44 - 4

Brakes / Mechanical Parts

Technical Data	46 - 01
Tightening Torques	46 - 05
Brake pads - checking	46 - 1
Brake pads - removing and installing	46 - 2
Stop light switch adjustment - checking	46 - 5
Parking brake - adjustment	46 - 6
Front wheel brake as from model 87, disassembly and assembly	46 - 7
Rear wheel brake, disassembly and assembly	46 - 9
Checking lateral runout of brake disk	46 - 10
Checking brake-disk thickness	46 - 11

Brakes / Hydraulics, Regulator, Booster

Tightening torque	47 - 01
Brake system information	47 - 02